

# ITEXMI Xpods Pro

## True Wireless Earbuds with ANC (Active Noise Cancellation) and ENC (Call Noise Cancellation)

### I. Important - Warnings and Safety Instructions

1. To prevent accidental ingestion, keep the earbuds out of reach from small children and pets.
2. Start with a low volume when inserting the earbuds into your ears and gradually adjust to a comfortable level.
3. Be aware that prolonged use at high volumes may cause hearing damage.
4. Prioritize your safety and the safety of others. We advise against using the earbuds while driving or cycling.
5. If you experience a warm sensation or loss of audio, remove and disconnect the earbuds immediately.
6. Avoid placing the product near heat sources.
7. Use only the accessories supplied by Itextmi.
8. Unplug the Charging Case once the earbuds are fully charged.
9. We recommend referring all servicing to qualified personnel.


**CAUTION:** Do NOT use the earbuds while swimming or showering.

### II. In the Box


- 1 x Itextmi Xpods Pro (Charging Case + 2 x Earbuds)
- 1 x USB Charging Cable
- 2 sets x silicon tips
- 1 x Quick Start Guide

### III. On-board Controls

#### 2. Charging Case



#### 1. Earbuds



#### IV. Button Operations

What to do	Regular Function	Alternate Function
Single Tap (L/R earbuds)	Play/Pause	Receive incoming Call
Long Touch for 2 secs (L earbud)	Voice Assistant	Reject incoming Call
Long Touch for 2 secs (R earbud)	ANC mode – Transparency mode	
Long Touch for 4 secs (L/R earbuds)	Power On/Off	
During Music Listening	Single Tap (L/R earbud): Play/Pause	
Double Tap	R earbud - Next Track	L earbud - Previous Track
Triple Tap	R earbud - Volume Up	L earbud - Volume Down
Single Tap (L/R earbuds)	During Calls: Receive Incoming Call	During Calls: End Call

#### IV. How to Wear

1. Insert the earbud into the ear.
2. Adjust and rotate the earbud until it fits comfortably and the microphone is pointing towards your mouth.

#### V. Charging

1. Earbuds: The earbuds charge while they are in the Charging Case. It takes approximately 30 minutes to fully charge the earbuds.
2. Charging Case: Plug the Charging Case into a USB Power Supply using the provided USB Type-C charging cable. Allow up to 2 hours to completely charge the Charging Case.

**Disclaimer: Please use only the Type-C charging cable for charging.**

#### VI. Bluetooth Pairing

1. TWS Mode: Take out any of the earbuds from the Charging Case. The earbud will flash red and blue alternately, indicating that it is ready to pair with a device. Find the device list and select "ITEXMI X-Pro".
2. Single Earbud: Take out any one of the earbuds from the Charging Case. The earbud will flash red and blue alternately, indicating that it is ready to pair with a device. Find the device list and select "ITEXMI X-Pro".

**Note:** Both buds can be connected separately with two different mobile phones and can be used as a single earbud.

#### VII. Care and Maintenance

1. Switch off the earbuds before cleaning.
2. Use a soft, damp cloth to clean the surface.
3. Avoid using chemicals, solvents, or cleaning solutions containing alcohol, ammonia, or abrasives.
4. Prevent any liquid from entering any of the openings.